REVISIONS

nted 5-1-69

6-AB3- 1 GENERAL NOTES & INDEX
6-AB3- 2 HORIZONTAL TRUSSES H1, H2
6-AB3- 3 HORIZONTAL TRUSSES H3, H4
6-AB3- 4 HORIZONTAL TRUSSES H5 - H9, H39, H40
6-AB3- 5 HORIZONTAL TRUSSES H10, H12, H57, H58
6-AB3- 6 HORIZONTAL TRUSSES H14, H15
6-AB3- 7 HORIZONTAL TRUSS DETAILS A & B
6-AB3- 8 HORIZONTAL TRUSS DETAILS C, D & DD
6-AB3- 9 HORIZONTAL TRUSS DETAILS F, G, H, & J
6-AB3-10 HORIZONTAL TRUSS DETAILS K-N, MM & NN
6-AB3-11 HORIZONTAL TRUSS DETAILS P, Q, R, T
6-AB3-11.1 HORIZONTAL TRUSS DETAILS V, W, VV
6-AB3-12 HORIZONTAL TRUSS DETAILS AA, BB, CC,
6-AB3-13 HORIZONTAL TRUSS DETAILS EE, FF
6-AB3-14 HORIZONTAL TRUSSES H20 - H22, H54 - H56
6-AB3-15 HORIZONTAL TRUSSES H23, H24, H52, H53
6-AB3-16 HORIZONTAL TRUSSES H25, H26
6-AB3-17 HORIZONTAL TRUSSES H27, H28, H51
6-AB3-18 HORIZONTAL TRUSSES H30, H34 - H37
6-AB3-19 HORIZONTAL TRUSSES H32, H33
6-AB3-20 HORIZONTAL TRUSSES H38
6-AB3-20.1 HORIZONTAL TRUSSES H31
6-AB3-21 HORIZONTAL TRUSS DETAILS HH, JJ, KK, LL, KKK, LLL
6-AB3-22 HORIZONTAL TRUSS DETAILS PP, QQ
6-AB3-23 HORIZONTAL TRUSS DETAILS RR, SS
6-AB3-24 HORIZONTAL TRUSS DETAILS TT
6-AB3-25 HORIZONTAL TRUSS DETAILS UU, WW
6-AB3-30 BRIDGING TYPE B1 THRU B4
6-AB3-31 BRIDGING TYPE B5 THRU B8
6-AB3-32 BRIDGING TYPE B9 THRU B12
6-AB3-33 BRIDGING DETAILS X, Y, Z, YY
6-AB3-34 HORIZONTAL TRUSSES H11, H13
6-AB3-35 HORIZONTAL TRUSSES H16, H17
6-AB3-36 HORIZONTAL TRUSSES H18, H19
6-AB3-37 HORIZONTAL TRUSSES H40, H41
6-AB3-38 HORIZONTAL TRUSS DETAILS A1, B1, C1

GENERAL NOTES.

1. ALL MATERIAL AND LABOR CONTRACT WTC 226.00 EXCEPT AS NOTED.
2. FOR EXTERIOR WALL COLUMNS, SPANDRELS AND SEATS SEE DRAWING BOOK 2 (FLOORS 7 & 9) WTC 213.00 AND DRAWING BOOK 4 (FLOORS 10 TO 110) WTC 214.00.



85